

# INTERNATIONAL STANDARD

## NORME INTERNATIONALE

**Adjustable speed electrical power drive systems –  
Part 7-303: Generic interface and use of profiles for power drive systems –  
Mapping of profile type 3 to network technologies**

**Entraînements électriques de puissance à vitesse variable –  
Partie 7-303: Interface générique et utilisation de profils pour les entraînements  
électriques de puissance – Mise en correspondance du profil de type 3 avec les  
technologies de réseaux**



**THIS PUBLICATION IS COPYRIGHT PROTECTED**  
**Copyright © 2007 IEC, Geneva, Switzerland**

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either IEC or IEC's member National Committee in the country of the requester.  
If you have any questions about IEC copyright or have an enquiry about obtaining additional rights to this publication, please contact the address below or your local IEC member National Committee for further information.

Droits de reproduction réservés. Sauf indication contraire, aucune partie de cette publication ne peut être reproduite ni utilisée sous quelque forme que ce soit et par aucun procédé, électronique ou mécanique, y compris la photocopie et les microfilms, sans l'accord écrit de la CEI ou du Comité national de la CEI du pays du demandeur.  
Si vous avez des questions sur le copyright de la CEI ou si vous désirez obtenir des droits supplémentaires sur cette publication, utilisez les coordonnées ci-après ou contactez le Comité national de la CEI de votre pays de résidence.

IEC Central Office  
3, rue de Varembe  
CH-1211 Geneva 20  
Switzerland

Tel.: +41 22 919 02 11  
Fax: +41 22 919 03 00  
[info@iec.ch](mailto:info@iec.ch)  
[www.iec.ch](http://www.iec.ch)

### About the IEC

The International Electrotechnical Commission (IEC) is the leading global organization that prepares and publishes International Standards for all electrical, electronic and related technologies.

### About IEC publications

The technical content of IEC publications is kept under constant review by the IEC. Please make sure that you have the latest edition, a corrigenda or an amendment might have been published.

#### Useful links:

IEC publications search - [www.iec.ch/searchpub](http://www.iec.ch/searchpub)

The advanced search enables you to find IEC publications by a variety of criteria (reference number, text, technical committee,...).

It also gives information on projects, replaced and withdrawn publications.

IEC Just Published - [webstore.iec.ch/justpublished](http://webstore.iec.ch/justpublished)

Stay up to date on all new IEC publications. Just Published details all new publications released. Available on-line and also once a month by email.

Electropedia - [www.electropedia.org](http://www.electropedia.org)

The world's leading online dictionary of electronic and electrical terms containing more than 30 000 terms and definitions in English and French, with equivalent terms in additional languages. Also known as the International Electrotechnical Vocabulary (IEV) on-line.

Customer Service Centre - [webstore.iec.ch/csc](http://webstore.iec.ch/csc)

If you wish to give us your feedback on this publication or need further assistance, please contact the Customer Service Centre: [csc@iec.ch](mailto:csc@iec.ch).

---

### A propos de la CEI

La Commission Electrotechnique Internationale (CEI) est la première organisation mondiale qui élabore et publie des Normes internationales pour tout ce qui a trait à l'électricité, à l'électronique et aux technologies apparentées.

### A propos des publications CEI

Le contenu technique des publications de la CEI est constamment revu. Veuillez vous assurer que vous possédez l'édition la plus récente. un corrigendum ou amendement peut avoir été publié.

#### Liens utiles:

Recherche de publications CEI - [www.iec.ch/searchpub](http://www.iec.ch/searchpub)

La recherche avancée vous permet de trouver des publications CEI en utilisant différents critères (numéro de référence, texte, comité d'études,...).

Elle donne aussi des informations sur les projets et les publications remplacées ou retirées.

Just Published CEI - [webstore.iec.ch/justpublished](http://webstore.iec.ch/justpublished)

Restez informé sur les nouvelles publications de la CEI. Just Published détaille les nouvelles publications parues. Disponible en ligne et aussi une fois par mois par email.

Electropedia - [www.electropedia.org](http://www.electropedia.org)

Le premier dictionnaire en ligne au monde de termes électroniques et électriques. Il contient plus de 30 000 termes et définitions en anglais et en français, ainsi que les termes équivalents dans les langues additionnelles. Egalement appelé Vocabulaire Electrotechnique International (VEI) en ligne.

Service Clients - [webstore.iec.ch/csc](http://webstore.iec.ch/csc)

Si vous désirez nous donner des commentaires sur cette publication ou si vous avez des questions contactez-nous: [csc@iec.ch](mailto:csc@iec.ch).

# INTERNATIONAL STANDARD

# NORME INTERNATIONALE



**Adjustable speed electrical power drive systems –  
Part 7-303: Generic interface and use of profiles for power drive systems –  
Mapping of profile type 3 to network technologies**

**Entraînements électriques de puissance à vitesse variable –  
Partie 7-303: Interface générique et utilisation de profils pour les entraînements  
électriques de puissance – Mise en correspondance du profil de type 3 avec les  
technologies de réseaux**

INTERNATIONAL  
ELECTROTECHNICAL  
COMMISSION

COMMISSION  
ELECTROTECHNIQUE  
INTERNATIONALE

PRICE CODE **XD**  
CODE PRIX

ICS 29.200; 35.100.05

ISBN 978-2-83220-713-0

**Warning! Make sure that you obtained this publication from an authorized distributor.  
Attention! Veuillez vous assurer que vous avez obtenu cette publication via un distributeur agréé.**

## CONTENTS

FOREWORD.....	7
INTRODUCTION.....	9
1 Scope.....	12
2 Normative references .....	12
3 Terms, definitions and abbreviated terms .....	13
3.1 Terms and definitions .....	13
3.2 Abbreviated terms .....	16
4 Mapping to PROFIBUS DP .....	19
4.1 General .....	19
4.2 Mapping to PROFIBUS data types.....	19
4.3 Base Model at PROFIBUS DP .....	19
4.3.1 Communication Devices .....	19
4.3.2 Communication Relationship .....	20
4.3.3 Communication Network.....	21
4.3.4 Communication Services .....	22
4.3.5 P-Device Communication Model.....	24
4.3.6 Base Model State Machine .....	25
4.3.7 Definition of the CO .....	26
4.4 Drive Model at PROFIBUS DP.....	26
4.4.1 P-Device .....	26
4.4.2 Drive Unit .....	27
4.5 DO IO Data .....	27
4.5.1 COs for DO IO Data configuration .....	27
4.5.2 Standard telegram configuration.....	28
4.5.3 Cyclic Data exchange between DP-Slaves (DXB).....	30
4.6 Parameter Access .....	39
4.6.1 RAP for Parameter Access .....	39
4.6.2 Definition of the Base Mode Parameter Access mechanism.....	40
4.7 P-Device Configuration.....	46
4.7.1 P-Device Configuration on PROFIBUS DP.....	46
4.7.2 Drive Unit Configuration on PROFIBUS DP .....	47
4.7.3 Getting the Drive Object – ID (DO-ID).....	49
4.8 Alarm Mechanism.....	51
4.9 Clock Synchronous Operation .....	51
4.9.1 Sequence of an isochronous DP cycle.....	51
4.9.2 Time settings.....	52
4.9.3 Running-up, cyclic operation .....	57
4.9.4 Parameterisation, configuring (Set_Prm, GSD).....	68
4.9.5 Clock cycle generation (Global Control) and clock cycle save.....	69
4.9.6 Monitoring mechanisms.....	73
4.10 PROFIBUS DP specific Parameter .....	75
4.10.1 Overview of the communication interface related parameters .....	75
4.10.2 Definition of the specific parameters.....	75
4.11 Specified communication functions for the Application Classes .....	76
5 Mapping to PROFINET IO .....	77

5.1	General .....	77
5.2	Mapping to PROFINET IO data types .....	77
5.3	Base Model at PROFINET IO .....	77
5.3.1	Communication Devices .....	77
5.3.2	Communication Relationship .....	78
5.3.3	Communication Network .....	79
5.3.4	Communication Services .....	80
5.3.5	P-Device Communication Model .....	81
5.3.6	Base Model State Machine .....	83
5.3.7	Definition of the CO .....	84
5.4	Drive Model at PROFINET IO .....	84
5.4.1	P-Device .....	84
5.4.2	Drive Unit .....	85
5.4.3	DO Architecture .....	85
5.4.4	Definition of the Module Ident Number and API .....	87
5.4.5	Definition of the Submodule Ident Number .....	87
5.5	DO IO Data .....	88
5.5.1	COs for DO IO Data configuration .....	88
5.5.2	IO Data Producer and Consumer Status .....	89
5.6	Parameter Access .....	89
5.6.1	PAPs for Parameter Access .....	89
5.6.2	Base Mode Parameter Access .....	90
5.7	P-Device Configuration .....	92
5.7.1	P-Device Configuration on PROFINET IO .....	92
5.7.2	Drive Unit Configuration on PROFINET IO .....	93
5.7.3	Getting the Drive Object – ID (DO-ID) .....	93
5.8	Alarm Mechanism .....	94
5.8.1	Use of the Diagnosis Objects .....	94
5.8.2	Use of the Alarm Mechanism .....	94
5.8.3	Use of the ChannelDiagnosisData Structure .....	95
5.8.4	Use of the ChannelErrorType .....	96
5.8.5	On demand access of Diagnosis Information .....	97
5.9	Clock Synchronous Operation .....	97
5.10	PROFINET IO specific Parameter .....	99
5.10.1	Overview about the communication interface related Parameters .....	99
5.10.2	Definition of the specific parameters .....	99
5.11	Specified communication functions for the Application Classes .....	100

Bibliography .....	102
--------------------	-----

Figure 1 – Structure of IEC 61800-7 .....	11
---	----

Figure 2 – PROFIBUS DP Devices in a PROFIdrive drive system .....	20
---	----

Figure 3 – PROFIdrive Devices and their Relationship for PROFIBUS DP .....	21
--	----

Figure 4 – General Communication Model for PROFIdrive at PROFIBUS DP .....	22
--	----

Figure 5 – PROFIBUS DP DXB communication designations .....	23
---	----

Figure 6 – Synchronous communication for PROFIdrive at PROFIBUS DP .....	24
--	----

Figure 7 – Overview about the P-Device Communication Model on PROFIBUS .....	24
--	----

Figure 8 – Mapping of the Base Model State Machine at PROFIBUS DP .....	26
---	----

Figure 9 – PROFIBUS DP specific Logical P-Device model (multi axis drive) .....	26
Figure 10 – Mapping of PROFIBUS Slot to the PROFIdrive DO .....	27
Figure 11 – Application example of DXB communication .....	32
Figure 12 – Dataflow inside a Homogeneous P-Device with DXB relations .....	35
Figure 13 – Structure of a DXB Subscriber table (inside a Prm-Block) .....	36
Figure 14 – Timing diagram of PROFIBUS with slave-to-slave communication .....	37
Figure 15 – PAP and Parameter Access mechanism for a PROFIBUS homogeneous P-Device .....	39
Figure 16 – PAP and Parameter Access mechanism for a PROFIBUS heterogeneous P-Device .....	40
Figure 17 – Telegram sequence via MS1 AR or MS2 AR .....	41
Figure 18 – Drive Unit Structure .....	48
Figure 19 – Configuration and communication channels for the Modular Drive Unit type at PROFIBUS DP .....	49
Figure 20 – Meaning of parameter P978 (list of all DO-Ids) for the DU at PROFIBUS DP .....	50
Figure 21 – Example of P978 for a complex Modular Drive Unit at PROFIBUS DP .....	51
Figure 22 – Sequence of an isochronous DP cycle .....	52
Figure 23 – Time settings .....	53
Figure 24 – Example: Simplest DP cycle .....	55
Figure 25 – Example: Optimised DP cycle .....	56
Figure 26 – Example: Optimised DP cycle ( $T_{MAPC} = 2 \times T_{DP}$ ) .....	57
Figure 27 – Running-up (sequence with respect to time) .....	58
Figure 28 – Phase 1: Slave parameterisation, configuration .....	59
Figure 29 – Phase 2: Synchronization of the PLL to the Clock Global Control .....	60
Figure 30 – Phase 3: Synchronization of the slave application with the master's Sign-Of-Life .....	62
Figure 31 – State diagram of phases 2 and 3 of the run-up .....	63
Figure 32 – Phase 4: Synchronization of the master application to the slave's Sign-Of-Life .....	64
Figure 33 – Example: Running-up to cyclic operation (Phase 1) ( $T_{MAPC}/T_{DP} = 2/1$ ) .....	65
Figure 34 – Example: Running-up to cyclic operation (Phase 2) ( $T_{MAPC}/T_{DP} = 2/1$ ) .....	65
Figure 35 – Example: Running-up to cyclic operation (Phase 3) ( $T_{MAPC}/T_{DP} = 2/1$ ) .....	66
Figure 36 – Example: Running-up to cyclic operation (Phase 4) ( $T_{MAPC}/T_{DP} = 2/1$ ) .....	67
Figure 37 – Example: Running-up to cyclic operation (Phase 5) ( $T_{MAPC}/T_{DP} = 2/1$ ) .....	67
Figure 38 – PLL for clock save in the slave .....	71
Figure 39 – Run time compensation .....	73
Figure 40 – DP cycle violation .....	74
Figure 41 – Example: Clock failure (fault after 4 DP cycles) .....	74
Figure 42 – PROFINET IO Devices in a PROFIdrive drive system .....	78
Figure 43 – PROFIdrive Devices and their Relationship for PROFINET IO .....	79
Figure 44 – General Communication Model for PROFIdrive at PROFINET IO .....	80
Figure 45 – Synchronous communication for PROFIdrive at PROFINET IO .....	81
Figure 46 – Overview about the P-Device Communication Model on PROFINET IO .....	81
Figure 47 – Contents of IO AR and Supervisor AR .....	82
Figure 48 – M CR used for Cyclic Data Exchange between P-Devices .....	83

Figure 49 – Mapping of the Base Model State Machine at PROFINET IO .....	84
Figure 50 – PROFINET IO specific Logical P-Device model (multi axis drive) .....	85
Figure 51 – Representation of the PROFIdrive DO by PROFINET IO Submodules (CO).....	86
Figure 52 – Hierarchical model of the P-Device on PROFINET IO.....	87
Figure 53 – Modularity of the DO IO Data block (example).....	89
Figure 54 – Data flow for request and response for the Base Mode Parameter Access .....	92
Figure 55 – Configuration and communication channels for the Modular Drive Unit type at PROFINET IO .....	93
Figure 56 – Meaning of parameter P978 "list of all DO-IDs" for the DU at PROFINET IO .....	94
Figure 57 – Generation of Diagnosis Data according to the fault classes mechanism.....	96
Figure 58 – Sequence of an isochronous Data Cycle .....	98
Table 1 – Mapping of data types .....	19
Table 2 – DP IDs and PROFIdrive IDs of the standard telegrams.....	28
Table 3 – 1 Drive Axis, standard telegram 3.....	29
Table 4 – 2 Drive Axes, standard telegram 3.....	30
Table 5 – 2 Drive Axes, standard telegram 3, per axis one DXB link each with 2 words .....	30
Table 6 – 1 Drive Axis, standard telegram 20.....	30
Table 7 – Slave No.11 (Publisher) .....	33
Table 8 – Slave No.12 (Publisher and Subscriber).....	33
Table 9 – Configuration of the DXB communication link of the coating drive .....	34
Table 10 – Slave No.10 (Subscriber).....	34
Table 11 – Configuration of the DXB communication links of the unwinder.....	34
Table 12 – Parameters (Set_Prm, GSD) for slave-to-slave communication (Data- eXchange Broadcast).....	38
Table 13 – Services used for Parameter Access on PROFIBUS DP .....	41
Table 14 – Defined PAPs for Parameter Access .....	41
Table 15 – State machine for DP-slave processing .....	42
Table 16 – MS1/MS2 AR telegram frame, Write request.....	42
Table 17 – MS1/MS2 AR telegram frame, Write response.....	43
Table 18 – MS1/MS2 AR telegram frame, Read request .....	43
Table 19 – MS1/MS2 AR telegram frame, Read response.....	43
Table 20 – Process data ASE telegram frame, Error response .....	44
Table 21 – Allocation of Error class and code for PROFIdrive .....	44
Table 22 – Data block lengths.....	45
Table 23 – Limits due to the Process data ASE data block length .....	46
Table 24 – GSD parameters for the MS1/MS2 AR services .....	46
Table 25 – DP Services for Running-up, cyclic operation .....	57
Table 26 – Parameters (Set_Prm, GSD) for "Clock Cycle Synchronous Drive Interface" .....	68
Table 27 – Possible synchronization type combinations .....	69
Table 28 – Conditions for Isochronous Mode .....	70
Table 29 – Input signals of the PLL.....	71
Table 30 – Output signals of the PLL .....	72

Table 31 – Overview of the specific PROFIBUS DP parameters for “Communication system interfaces” .....	75
Table 32 – PROFIdrive Specific Parameter listed by number .....	75
Table 33 – Coding of the baud rate in Parameter 963 .....	76
Table 34 – Specified communication functions for the Application Classes .....	76
Table 35 – Mapping of data types .....	77
Table 36 – Structure of the Submodule-ID .....	88
Table 37 – Definition of Submodule-Type Classes .....	88
Table 38 – Definition of Parameter Access Modes (PAP) .....	90
Table 39 – Use of the AlarmNotification-PDU .....	95
Table 40 – Use of ChannelDiagnosisData .....	95
Table 41 – Use of ChannelErrorType .....	96
Table 42 – Use of the DiagnosisData .....	97
Table 43 – Overview of the specific PROFINET IO parameters for “Communication system interfaces” .....	99
Table 44 – PROFIdrive Specific Parameter listed by number .....	99
Table 45 – Specified communication functions for the Application Classes .....	101

Withdrawing