

# INTERNATIONAL STANDARD

**Adjustable speed electrical power drive systems –  
Part 7-201: Generic interface and use of profiles for power drive systems –  
Profile type 1 specification**

Withdrawn



## THIS PUBLICATION IS COPYRIGHT PROTECTED

Copyright © 2007 IEC, Geneva, Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either IEC or IEC's member National Committee in the country of the requester.

If you have any questions about IEC copyright or have an enquiry about obtaining additional rights to this publication, please contact the address below or your local IEC member National Committee for further information.

IEC Central Office  
3, rue de Varembe  
CH-1211 Geneva 20  
Switzerland  
Email: [inmail@iec.ch](mailto:inmail@iec.ch)  
Web: [www.iec.ch](http://www.iec.ch)

### About the IEC

The International Electrotechnical Commission (IEC) is the leading global organization that prepares and publishes International Standards for all electrical, electronic and related technologies.

### About IEC publications

The technical content of IEC publications is kept under constant review by the IEC. Please make sure that you have the latest edition, a corrigenda or an amendment might have been published.

- Catalogue of IEC publications: [www.iec.ch/searchpub](http://www.iec.ch/searchpub)

The IEC on-line Catalogue enables you to search by a variety of criteria (reference number, text, technical committee,...). It also gives information on projects, withdrawn and replaced publications.

- IEC Just Published: [www.iec.ch/online\\_news/justpub](http://www.iec.ch/online_news/justpub)

Stay up to date on all new IEC publications. Just Published details twice a month all new publications released. Available on-line and also by email.

- Electropedia: [www.electropedia.org](http://www.electropedia.org)

The world's leading online dictionary of electronic and electrical terms containing more than 20 000 terms and definitions in English and French, with equivalent terms in additional languages. Also known as the International Electrotechnical Vocabulary online.

- Customer Service Centre: [www.iec.ch/webstore/custserv](http://www.iec.ch/webstore/custserv)

If you wish to give us your feedback on this publication or need further assistance, please visit the Customer Service Centre FAQ or contact us:

Email: [csc@iec.ch](mailto:csc@iec.ch)  
Tel.: +41 22 919 02 11  
Fax: +41 22 919 03 00

# INTERNATIONAL STANDARD

---

**Adjustable speed electrical power drive systems –  
Part 7-201: Generic interface and use of profiles for power drive systems –  
Profile type 1 specification**

INTERNATIONAL  
ELECTROTECHNICAL  
COMMISSION

PRICE CODE **XG**

Withhold

## CONTENTS

FOREWORD.....	14
INTRODUCTION.....	16
1 Scope.....	19
2 Normative references .....	19
3 Terms, definitions and abbreviated terms .....	19
3.1 Terms and definitions .....	19
3.2 Abbreviated terms .....	23
4 General .....	24
4.1 General considerations.....	24
4.2 Communication interface .....	24
4.3 Object dictionary .....	25
5 Data types.....	25
5.1 Standard data types .....	25
5.2 Record definitions .....	26
6 General object definitions.....	27
6.1 General.....	27
6.2 Communication parameter objects.....	27
6.3 Additional identification and information objects .....	28
6.3.1 Object 6402 <sub>h</sub> : Motor type .....	28
6.3.2 Object 6403 <sub>h</sub> : Motor catalogue number .....	29
6.3.3 Object 6404 <sub>h</sub> : Motor manufacturer.....	29
6.3.4 Object 6405 <sub>h</sub> : http motor catalogue address.....	30
6.3.5 Object 6406 <sub>h</sub> : Motor calibration date .....	30
6.3.6 Object 6407 <sub>h</sub> : Motor service period .....	31
6.3.7 Object 6503 <sub>h</sub> : Drive catalogue number .....	31
6.3.8 Object 6505 <sub>h</sub> : http drive catalogue address .....	32
7 Error codes and error behaviour .....	32
7.1 Error codes.....	32
7.2 Error behavior .....	36
8 Controlling the power drive system .....	37
8.1 General.....	37
8.2 Finite state automaton.....	37
8.3 Modes of operation.....	40
8.4 Detailed object specifications .....	41
8.4.1 Object 6040 <sub>h</sub> : Controlword .....	41
8.4.2 Object 6041 <sub>h</sub> : Statusword.....	42
8.4.3 Object 603F <sub>h</sub> : Error code .....	43
8.4.4 Object 6007 <sub>h</sub> : Abort connection option code.....	44
8.4.5 Object 605A <sub>h</sub> : Quick stop option code .....	45
8.4.6 Object 605B <sub>h</sub> : Shutdown option code .....	46
8.4.7 Object 605C <sub>h</sub> : Disable operation option code .....	46
8.4.8 Object 605D <sub>h</sub> : Halt option code .....	47
8.4.9 Object 605E <sub>h</sub> : Fault reaction option code .....	48
8.4.10 Object 6060 <sub>h</sub> : Modes of operation .....	49
8.4.11 Object 6061 <sub>h</sub> : Modes of operation display .....	50

8.4.12	Object 6502 <sub>h</sub> : Supported drive modes .....	50
9	Factor group .....	51
9.1	General .....	51
9.2	Detailed object definitions .....	51
9.2.1	Object 608F <sub>h</sub> : Position encoder resolution .....	51
9.2.2	Object 6090 <sub>h</sub> : Velocity encoder resolution .....	52
9.2.3	Object 6091 <sub>h</sub> : Gear ratio .....	53
9.2.4	Object 6092 <sub>h</sub> : Feed constant .....	54
9.2.5	Object 607E <sub>h</sub> : Polarity .....	55
10	Profile position mode .....	56
10.1	General information .....	56
10.2	Functional description .....	57
10.2.1	General .....	57
10.2.2	Single set-point .....	58
10.2.3	Set of set-points .....	59
10.3	General definitions .....	60
10.4	Use of controlword and statusword .....	60
10.5	Detailed object definitions .....	61
10.5.1	Object 607A <sub>h</sub> : Target position .....	61
10.5.2	Object 607B <sub>h</sub> : Position range limit .....	62
10.5.3	Object 607D <sub>h</sub> : Software position limit .....	62
10.5.4	Object 607F <sub>h</sub> : Max profile velocity .....	64
10.5.5	Object 6080 <sub>h</sub> : Max motor speed .....	64
10.5.6	Object 6081 <sub>h</sub> : Profile velocity .....	65
10.5.7	Object 6082 <sub>h</sub> : End velocity .....	65
10.5.8	Object 6083 <sub>h</sub> : Profile acceleration .....	66
10.5.9	Object 6084 <sub>h</sub> : Profile deceleration .....	66
10.5.10	Object 6085 <sub>h</sub> : Quick stop deceleration .....	67
10.5.11	Object 6086 <sub>h</sub> : Motion profile type .....	67
10.5.12	Object 60A3 <sub>h</sub> : Profile jerk use .....	68
10.5.13	Object 60A4 <sub>h</sub> : Profile jerk .....	69
10.5.14	Object 60C5 <sub>h</sub> : Max acceleration .....	70
10.5.15	Object 60C6 <sub>h</sub> : Max deceleration .....	71
11	Homing mode .....	72
11.1	General information .....	72
11.2	Functional description .....	72
11.3	General definitions .....	73
11.3.1	Method 1: Homing on negative limit switch and index pulse .....	73
11.3.2	Method 2: Homing on positive limit switch and index pulse .....	73
11.3.3	Method 3 and 4: Homing on positive home switch and index pulse .....	73
11.3.4	Method 5 and 6: Homing on negative home switch and index pulse .....	74
11.3.5	Method 7 to 14: Homing on home switch and index pulse .....	74
11.3.6	Method 15 and 16: Reserved .....	75
11.3.7	Method 17 to 30: Homing without index pulse .....	75
11.3.8	Method 31 and 32: Reserved .....	76
11.3.9	Method 33 and 34: Homing on index pulse .....	76
11.3.10	Method 35: Homing on index pulse .....	76
11.3.11	Method 36: Homing with touch-probe .....	76
11.4	Use of controlword and statusword .....	76

11.5	Detailed object definitions .....	77
11.5.1	Object 607C <sub>h</sub> : Home offset .....	77
11.5.2	Object 6098 <sub>h</sub> : Homing method .....	78
11.5.3	Object 6099 <sub>h</sub> : Homing speeds .....	79
11.5.4	Object 609A <sub>h</sub> : Homing acceleration .....	80
11.5.5	Object 60B8 <sub>h</sub> : Touch probe function .....	80
11.5.6	Object 60B9 <sub>h</sub> : Touch probe status .....	82
11.5.7	Object 60BA <sub>h</sub> : Touch probe pos1 pos value .....	82
11.5.8	Object 60BB <sub>h</sub> : Touch probe pos1 neg value .....	83
11.5.9	Object 60BC <sub>h</sub> : Touch probe pos2 pos value .....	83
11.5.10	Object 60BD <sub>h</sub> : Touch probe pos2 neg value .....	84
12	Position control function .....	84
12.1	General information .....	84
12.2	Functional description .....	85
12.3	Detailed object definitions .....	87
12.3.1	Object 6062 <sub>h</sub> : Position demand value .....	87
12.3.2	Object 6063 <sub>h</sub> : Position actual internal value .....	87
12.3.3	Object 6064 <sub>h</sub> : Position actual value .....	88
12.3.4	Object 6065 <sub>h</sub> : Following error window .....	88
12.3.5	Object 6066 <sub>h</sub> : Following error time out .....	89
12.3.6	Object 6067 <sub>h</sub> : Position window .....	90
12.3.7	Object 6068 <sub>h</sub> : Position window time .....	90
12.3.8	Object 60F4 <sub>h</sub> : Following error actual value .....	91
12.3.9	Object 60FA <sub>h</sub> : Control effort .....	91
12.3.10	Object 60FC <sub>h</sub> : Position demand internal value .....	92
12.3.11	Object 60F2 <sub>h</sub> : Positioning option code .....	92
13	Interpolated position mode .....	94
13.1	General information .....	94
13.2	Functional description .....	95
13.2.1	General .....	95
13.2.2	Linear interpolated position mode with several axes .....	96
13.2.3	Buffer strategies for the interpolated position mode .....	97
13.2.4	Interpolated position mode FSA .....	98
13.3	General definitions .....	99
13.4	Use of controlword and statusword .....	99
13.5	Detailed object definitions .....	100
13.5.1	Object 60C0 <sub>h</sub> : Interpolation sub mode select .....	100
13.5.2	Object 60C1 <sub>h</sub> : Interpolation data record .....	101
13.5.3	Object 60C2 <sub>h</sub> : Interpolation time period .....	102
13.5.4	Object 60C4 <sub>h</sub> : Interpolation data configuration .....	103
14	Profile velocity mode .....	105
14.1	General information .....	105
14.2	Functional description .....	106
14.3	General definitions .....	107
14.4	Use of controlword and statusword .....	107
14.5	Detailed object definitions .....	108
14.5.1	Object 6069 <sub>h</sub> : Velocity sensor actual value .....	108
14.5.2	Object 606A <sub>h</sub> : Sensor selection code .....	108
14.5.3	Object 606B <sub>h</sub> : Velocity demand value .....	109

14.5.4	Object 606C <sub>h</sub> : Velocity actual value .....	110
14.5.5	Object 606D <sub>h</sub> : Velocity window .....	110
14.5.6	Object 606E <sub>h</sub> : Velocity window time .....	111
14.5.7	Object 606F <sub>h</sub> : Velocity threshold .....	111
14.5.8	Object 6070 <sub>h</sub> : Velocity threshold time .....	112
14.5.9	Object 60FF <sub>h</sub> : Target velocity .....	112
14.5.10	Object 60F8 <sub>h</sub> : Max slippage .....	113
15	Profile torque mode .....	113
15.1	General information .....	113
15.2	Functional description .....	113
15.3	General definitions .....	114
15.4	Use of controlword and statusword .....	114
15.5	Detailed object definitions .....	115
15.5.1	Object 6071 <sub>h</sub> : Target torque .....	115
15.5.2	Object 6072 <sub>h</sub> : Max torque .....	116
15.5.3	Object 6073 <sub>h</sub> : Max current .....	116
15.5.4	Object 6074 <sub>h</sub> : Torque demand .....	117
15.5.5	Object 6075 <sub>h</sub> : Motor rated current .....	117
15.5.6	Object 6076 <sub>h</sub> : Motor rated torque .....	118
15.5.7	Object 6077 <sub>h</sub> : Torque actual value .....	118
15.5.8	Object 6078 <sub>h</sub> : Current actual value .....	119
15.5.9	Object 6079 <sub>h</sub> : DC link circuit voltage .....	119
15.5.10	Object 6087 <sub>h</sub> : Torque slope .....	120
15.5.11	Object 6088 <sub>h</sub> : Torque profile type .....	120
16	Velocity mode .....	121
16.1	General information .....	121
16.2	Functional description .....	122
16.2.1	Velocity limit function .....	122
16.2.2	Ramp function .....	122
16.2.3	Velocity control function .....	122
16.2.4	Factor function .....	122
16.3	General definitions .....	123
16.4	Use of controlword and statusword .....	123
16.5	Detailed object definitions .....	124
16.5.1	Object 6042 <sub>h</sub> : v <sub>l</sub> target velocity .....	124
16.5.2	Object 6043 <sub>h</sub> : v <sub>l</sub> velocity demand .....	125
16.5.3	Object 6044 <sub>h</sub> : v <sub>l</sub> velocity actual value .....	125
16.5.4	Object 6046 <sub>h</sub> : v <sub>l</sub> velocity min max amount .....	126
16.5.5	Object 6049 <sub>h</sub> : v <sub>l</sub> velocity deceleration .....	127
16.5.6	Object 6048 <sub>h</sub> : v <sub>l</sub> velocity acceleration .....	128
16.5.7	Object 604A <sub>h</sub> : v <sub>l</sub> velocity quick stop .....	130
16.5.8	Object 604B <sub>h</sub> : v <sub>l</sub> set-point factor .....	131
16.5.9	Object 604C <sub>h</sub> : v <sub>l</sub> dimension factor .....	132
17	Cyclic synchronous position mode .....	133
17.1	General information .....	133
17.2	Functional description .....	134
17.3	Use of controlword and statusword .....	135
17.4	Detailed object definitions .....	136
17.4.1	Object 60B0 <sub>h</sub> : Position offset .....	136

17.4.2	Object 60B1 <sub>h</sub> : Velocity offset.....	136
17.4.3	Object 60B2 <sub>h</sub> : Torque offset.....	137
18	Cyclic synchronous velocity mode.....	137
18.1	General information.....	137
18.2	General definitions.....	138
18.3	Functional description.....	138
18.4	Use of controlword and statusword.....	139
19	Cyclic synchronous torque mode.....	140
19.1	General information.....	140
19.2	General definitions.....	140
19.3	Functional description.....	140
19.4	Use of controlword and statusword.....	141
20	Optional application FE.....	141
20.1	General.....	141
20.2	Object 60FD <sub>h</sub> : Digital inputs.....	141
20.3	Object 60FE <sub>h</sub> : Digital outputs.....	142
	Bibliography.....	144
	Figure 1 – Structure of IEC 61800-7.....	18
	Figure 2 – Value definition.....	27
	Figure 3 – Remote and local control.....	37
	Figure 4 – Power drive system finite state automaton.....	38
	Figure 5 – Relation between different value parameters.....	41
	Figure 6 – Value definition.....	41
	Figure 7 – Value definition.....	42
	Figure 8 – Value definition.....	50
	Figure 9 – Value definition.....	56
	Figure 10 – Trajectory generator and position control function.....	56
	Figure 11 – Trajectory generator for profile position mode.....	57
	Figure 12 – Set-point example.....	58
	Figure 13 – Handshaking procedure for the single set-point method.....	58
	Figure 14 – Handshaking procedure for the set of set-points method.....	59
	Figure 15 – Set-point handling for two set-points.....	59
	Figure 16 – Controlword for profile position (pp) mode.....	60
	Figure 17 – Statusword for profile position (pp) mode.....	61
	Figure 18 – Velocity/time diagram with jerk positions.....	69
	Figure 19 – Homing mode function.....	72
	Figure 20 – Homing on negative limit switch and index pulse.....	73
	Figure 21 – Homing on positive limit switch and index pulse.....	73
	Figure 22 – Homing on positive home switch and index pulse.....	74
	Figure 23 – Homing on negative home switch and index pulse.....	74
	Figure 24 – Homing on home switch and index pulse – positive initial motion.....	75
	Figure 25 – Homing on home switch and index pulse – negative initial motion.....	75
	Figure 26 – Homing on positive home switch.....	76