

INTERNATIONAL STANDARD

**Adjustable speed electrical power drive systems –
Part 7-203: Generic interface and use of profiles for power drive systems –
Profile type 3 specification**

Withdrawn



THIS PUBLICATION IS COPYRIGHT PROTECTED

Copyright © 2007 IEC, Geneva, Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either IEC or IEC's member National Committee in the country of the requester.

If you have any questions about IEC copyright or have an enquiry about obtaining additional rights to this publication, please contact the address below or your local IEC member National Committee for further information.

IEC Central Office
3, rue de Varembe
CH-1211 Geneva 20
Switzerland
Email: inmail@iec.ch
Web: www.iec.ch

About the IEC

The International Electrotechnical Commission (IEC) is the leading global organization that prepares and publishes International Standards for all electrical, electronic and related technologies.

About IEC publications

The technical content of IEC publications is kept under constant review by the IEC. Please make sure that you have the latest edition, a corrigenda or an amendment might have been published.

- Catalogue of IEC publications: www.iec.ch/searchpub

The IEC on-line Catalogue enables you to search by a variety of criteria (reference number, text, technical committee,...). It also gives information on projects, withdrawn and replaced publications.

- IEC Just Published: www.iec.ch/online_news/justpub

Stay up to date on all new IEC publications. Just Published details twice a month all new publications released. Available on-line and also by email.

- Electropedia: www.electropedia.org

The world's leading online dictionary of electronic and electrical terms containing more than 20 000 terms and definitions in English and French, with equivalent terms in additional languages. Also known as the International Electrotechnical Vocabulary online.

- Customer Service Centre: www.iec.ch/webstore/custserv

If you wish to give us your feedback on this publication or need further assistance, please visit the Customer Service Centre FAQ or contact us:

Email: csc@iec.ch
Tel.: +41 22 919 02 11
Fax: +41 22 919 03 00

INTERNATIONAL STANDARD

**Adjustable speed electrical power drive systems –
Part 7-203: Generic interface and use of profiles for power drive systems –
Profile type 3 specification**

INTERNATIONAL
ELECTROTECHNICAL
COMMISSION

PRICE CODE **XH**

Withhold

CONTENTS

FOREWORD.....	10
INTRODUCTION.....	12
1 Scope.....	15
2 Normative references	15
3 Terms, definitions and abbreviated terms	16
3.1 Terms and definitions	16
3.2 Abbreviated terms	20
4 General	21
4.1 Background	21
4.2 Requirements	22
4.3 Goals of the PROFIdrive Profile	22
5 Data types	22
5.1 Data types overview	22
5.2 Standard data types	23
5.3 Profile-specific data types	23
5.3.1 General	23
5.3.2 Normalised value: N2, N4	24
5.3.3 Normalised value (variable normalisation): X2, X4	24
5.3.4 Fixed point value: E2	25
5.3.5 Fixed point value: C4	25
5.3.6 Bit sequence: V2	26
5.3.7 Nibble: L2	26
5.3.8 Time constant: T2, T4	26
5.3.9 Time constant: D2	27
5.3.10 Reciprocal time constant: R2	27
6 Specifications	27
6.1 Integration of drives in automation systems	27
6.1.1 General	27
6.1.2 Base Model	27
6.1.3 Drive Model	35
6.1.4 P-Device communication model	39
6.1.5 Application Model and Application Classes	40
6.2 Parameter model	46
6.2.1 Parameter definition	46
6.2.2 Global and Local Parameters	58
6.2.3 Base Mode Parameter Access	59
6.3 Drive control application process	78
6.3.1 General Axis type Drive Object architecture	78
6.3.2 Control and Status words	81
6.3.3 Operating modes and State Machine	87
6.3.4 DO IO Data	103
6.3.5 Dynamic Servo Control (DSC)	114
6.3.6 Position feedback interface	118
6.3.7 Periphery	140
6.3.8 Warnings, messages, faults, diagnostics	141

6.3.9	Identification.....	150
6.3.10	Drive reset (power-on reset).....	153
6.3.11	Operation priority of parameters and control priority.....	155
6.3.12	User data reliability.....	157
6.3.13	Specified DO functions for the Application Classes.....	161
6.4	Parameter Definition.....	163
6.4.1	PROFIdrive Parameter listed by Function.....	163
6.4.2	PROFIdrive Parameter listed by number.....	167
6.5	Integration of Drives in Process Technology (VIK-NAMUR).....	176
6.5.1	General.....	176
6.5.2	Commands and Checkback Signals.....	177
6.5.3	State diagrams.....	179
6.5.4	Inevitable line interruption and external interlock.....	181
6.5.5	Standard telegram.....	182
	Bibliography.....	184
	Figure 1 – Structure of IEC 61800-7.....	14
	Figure 2 – PROFIdrive Devices and there relationship.....	28
	Figure 3 – General Communication Model of a PROFIdrive Automation System.....	29
	Figure 4 – The PROFIdrive Device (consists of one or several Functional Objects).....	30
	Figure 5 – Hierarchical order in the Object Model.....	31
	Figure 6 – PROFIdrive Base Model contains the “Application Layer” and “Communication Layer”.....	32
	Figure 7 – Typical use case for Clock Synchronous Operation.....	33
	Figure 8 – General Model for Clock Synchronous Operation.....	34
	Figure 9 – Base Model State Machine.....	35
	Figure 10 – General Drive Unit model.....	36
	Figure 11 – General Drive Object architecture.....	37
	Figure 12 – Principle functional model of an Axis type Drive Object.....	37
	Figure 13 – Classes of PROFIdrive P-Devices.....	38
	Figure 14 – Classes of PROFIdrive Drive Units.....	39
	Figure 15 – Overview about the available Communication Services between the PROFIdrive Devices.....	39
	Figure 16 – Application Class 1.....	41
	Figure 17 – Application Class 2.....	42
	Figure 18 – Application Class 3.....	43
	Figure 19 – Application Class 4.....	44
	Figure 20 – Application Class 5.....	45
	Figure 21 – Application Class 6.....	46
	Figure 22 – Example overview of global and local parameters of a Multi-Axis/Modular Drive Unit.....	59
	Figure 23 – Byte order for Words and Double words.....	60
	Figure 24 – Data flow for Base Mode Parameter Access.....	67
	Figure 25 – General functional elements of the PROFIdrive Axis type DO.....	79
	Figure 26 – Functional block diagram of the PROFIdrive Axis type DO.....	80

Figure 27 – General state diagram for all operating modes	89
Figure 28 – General functionality of a PROFIdrive Axis DO with Application Class 1 functionality	91
Figure 29 – Speed setpoint channel for use in Application Class 1 and 4	92
Figure 30 – General functionality of a PROFIdrive Axis DO with Application Class 4 functionality	93
Figure 31 – Reduced speed setpoint channel for use in Application Class 4 (optional).....	94
Figure 32 – General functionality of a PROFIdrive Axis DO with Application Class 3 functionality	95
Figure 33 – Functionality of the Motion Controller in the Program submode	96
Figure 34 – Functionality of the Motion Controller in the MDI submode	97
Figure 35 – State diagram of the positioning mode in Program-submode	99
Figure 36 – State diagram of the positioning mode in MDI-submode	100
Figure 37 – Homing Procedure: Home Position Set.....	101
Figure 38 – Homing Procedure: Abortion by the controller	101
Figure 39 – Traversing Task Active.....	102
Figure 40 – Change of the traversing tasks immediately	102
Figure 41 – Example for configuring a telegram	111
Figure 42 – Structure of the position control circuit based on the velocity setpoint interface without DSC	114
Figure 43 – Structure of the position control circuit based on the velocity setpoint interface with DSC	115
Figure 44 – Example of the sensor interface (Sensor-1: two actual values/Sensor-2: one actual value)	119
Figure 45 – Actual value format, example 1	123
Figure 46 – Actual value format, example 2	123
Figure 47 – Actual value format, example 3	123
Figure 48 – Actual value format, example 4	124
Figure 49 – Actual value format, example 5	124
Figure 50 – Actual value format, example 6	124
Figure 51 – Actual value format, example 7	124
Figure 52 – Actual value format, example 8	125
Figure 53 – State diagram of the position feedback interface with designations of the states and transitions.....	130
Figure 54 – Acknowledgement of acknowledgeable sensor error.....	135
Figure 55 – Acknowledgement of unacknowledgeable sensor error.....	136
Figure 56 – Timing diagram: Measurement on the fly – sequence 1	137
Figure 57 – Timing diagram: Measurement on the fly – sequence 2	138
Figure 58 – Timing diagram: Reference mark search	139
Figure 59 – Overview about the diagnostic mechanisms of PROFIdrive	141
Figure 60 – Working of the warning mechanism	142
Figure 61 – Overview about the fault buffer mechanism	143
Figure 62 – Fault acknowledgement for the fault buffer mechanism	144
Figure 63 – Processing of the fault messages in the fault buffer mechanism	145
Figure 64 – Fault buffer (subsequent system) with example	147

Figure 65 – Fault number list with example	148
Figure 66 – Drive reset: Direct initiation (P972 = 1).....	155
Figure 67 – Example: Long term Sign-Of-Life failure of the controller.....	158
Figure 68 – Example: Temporary failure of the controller LS (negative deviation)	158
Figure 69 – Example: Temporary failure of the controller LS (positive deviation; double step)	158
Figure 70 – Example: Permanent failure of the DO LS	159
Figure 71 – Example: Temporary failure of the DO LS (negative deviation).....	160
Figure 72 – Example: Temporary failure of the DO LS (positive deviation; double step)	160
Figure 73 – Value of the DO Sign-Of-Life failure counter (axis-specific) with respect to the transferred controller Sign-Of-Life	161
Figure 74 – Functionality and Interfaces for drive integration according to VIK-NAMUR	176
Figure 75 – Principle structure of the drive interface according to VIK-NAMUR guideline.....	177
Figure 76 – Speed setpoint channel for VIK-NAMUR process technology operating mode	180
Figure 77 – Process technology operating mode, control word 1 bit 15 and status word 1 bit 10,11,13,14.....	181
Figure 78 – Process technology operating mode, inevitable line interruption and external interlock	182
Table 1 – Standard data types	23
Table 2 – Profile specific data types	23
Table 3 – N2, N4-Range of values	24
Table 4 – N2, N4-Coding	24
Table 5 – X2, X4-Range of values.....	25
Table 6 – X2, X4-Coding (example x=12/28).....	25
Table 7 – E2-Range of values.....	25
Table 8 – E2-Coding	25
Table 9 – C4-Range of values.....	26
Table 10 – V2-Coding	26
Table 11 – L2-Coding	26
Table 12 – T2, T4-Range of values	26
Table 13 – D2-Range of values	27
Table 14 – R2-Range of values.....	27
Table 15 – Application Classes	40
Table 16 – Parameter definition	46
Table 17 – Parameter description elements	47
Table 18 – Parameter description element "Identifier (ID)"	48
Table 19 – Parameter description element "variable attribute"	48
Table 20 – Variable index and conversion index for SI units	49
Table 21 – Conversion values for the conversion index (SI units).....	53
Table 22 – Variable index and conversion index for US units	54
Table 23 – Conversion values for the conversion index (US units)	55

Table 24 – Parameter Description Elements “IO Data Reference Value/IO Data Normalisation”	57
Table 25 – Text array for parameter description	57
Table 26 – Text array for the data type Boolean.....	58
Table 27 – Text array for data type V2 (bit sequence).....	58
Table 28 – Base mode parameter request.....	61
Table 29 – Base mode parameter response	61
Table 30 – Permissible combinations consisting of attribute, number of elements and subindex	64
Table 31 – Coding of the fields in parameter request/parameter response of Base Mode Parameter Access	64
Table 32 – Error numbers in Base Mode parameter responses	65
Table 33 – General State machine for the Parameter Manager Processing.....	67
Table 34 – Sequence 1: Parameter request	68
Table 35 – Sequence 1: Parameter response positive with data of data type Word	68
Table 36 – Sequence 1: Parameter response positive with data of data type Double word	69
Table 37 – Sequence 1: Parameter response, negative	69
Table 38 – Sequence 2: Parameter request	69
Table 39 – Sequence 2: Parameter response, positive.....	69
Table 40 – Sequence 2: Parameter response, negative	70
Table 41 – Sequence 3: Parameter request.....	70
Table 42 – Sequence 3: Parameter response, positive.....	70
Table 43 – Sequence 3: Parameter response, negative	70
Table 44 – Sequence 4: Parameter request	71
Table 45 – Sequence 4: Parameter response, positive.....	71
Table 46 – Sequence 4: Parameter response, negative	71
Table 47 – Sequence 5: Parameter request	71
Table 48 – Sequence 5: Parameter response, positive.....	72
Table 49 – Sequence 5: Parameter response, negative	72
Table 50 – Sequence 6: Parameter request	72
Table 51 – Sequence 6: Parameter response (+): all partial accesses OK.....	73
Table 52 – Sequence 6: Parameter response (-): first and third partial access OK, second partial access erroneous.....	73
Table 53 – Sequence 7: Parameter request	73
Table 54 – Sequence 7: Parameter response (+): all partial accesses OK.....	74
Table 55 – Sequence 7: Parameter response (-): first and third partial access OK, second partial access erroneous.....	74
Table 56 – Sequence 8: Parameter request	75
Table 57 – Sequence 8: Parameter response positive with data of the data type word (for example ID).....	75
Table 58 – Sequence 8: Parameter response positive with text.....	75
Table 59 – Sequence 8: Parameter response, negative	75
Table 60 – Sequence 9: Parameter request	76
Table 61 – Sequence 9: Parameter response, positive.....	76