

INTERNATIONAL STANDARD



**Industrial communication networks – Fieldbus specifications –
Part 5 3: Application layer service definition – Type 3 elements**



THIS PUBLICATION IS COPYRIGHT PROTECTED

Copyright © 2010 IEC, Geneva, Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either IEC or IEC's member National Committee in the country of the requester.

If you have any questions about IEC copyright or have an enquiry about obtaining additional rights to this publication, please contact the address below or your local IEC member National Committee for further information.

IEC Central Office
3, rue de Varembe
CH-1211 Geneva 20
Switzerland
Email: inmail@iec.ch
Web: www.iec.ch

About the IEC

The International Electrotechnical Commission (IEC) is the leading global organization that prepares and publishes International Standards for all electrical, electronic and related technologies.

About IEC publications

The technical content of IEC publications is kept under constant review by the IEC. Please make sure that you have the latest edition, a corrigenda or an amendment might have been published.

- Catalogue of IEC publications: www.iec.ch/searchpub

The IEC on-line Catalogue enables you to search by a variety of criteria (reference number, text, technical committee,...). It also gives information on projects, withdrawn and replaced publications.

- IEC Just Published: www.iec.ch/online_news/justpub

Stay up to date on all new IEC publications. Just Published details twice a month all new publications released. Available on-line and also by email.

- Electropedia: www.electropedia.org

The world's leading online dictionary of electronic and electrical terms containing more than 20 000 terms and definitions in English and French, with equivalent terms in additional languages. Also known as the International Electrotechnical Vocabulary online.

- Customer Service Centre: www.iec.ch/webstore/custserv

If you wish to give us your feedback on this publication or need further assistance, please visit the Customer Service Centre FAQ or contact us:

Email: csc@iec.ch
Tel.: +41 22 919 02 11
Fax: +41 22 919 03 00



IEC 61158-5-3

Edition 2.0 2010-08

INTERNATIONAL STANDARD



**Industrial communication networks – Fieldbus specifications –
Part 5 3: Application layer service definition – Type 3 elements**

INTERNATIONAL
ELECTROTECHNICAL
COMMISSION

PRICE CODE **XH**

ICS 25.04.40; 35.100.70; 35.110

ISBN 978-2-88912-106-9

IEC 61158-5-3 Ed. 2.0 - Preview only Copy via ILNAS e-Shop

Without a name

CONTENTS

FOREWORD.....	11
INTRODUCTION.....	13
1 Scope.....	14
1.1 General.....	14
1.2 Overview.....	14
1.3 Specifications.....	15
1.4 Conformance.....	15
2 Normative references.....	15
3 Terms, definitions, abbreviations, symbols and conventions.....	16
3.1 Referenced terms and definitions.....	16
3.2 Fieldbus Application Layer type 3 – specific terms and definitions.....	17
3.3 Abbreviations and symbols.....	25
3.4 Conventions.....	25
4 Concepts.....	32
5 Data type ASE.....	32
6 Communication model specification.....	32
6.1 DP concepts.....	32
6.2 ASEs.....	52
6.3 Summary of FAL classes.....	430
6.4 Permitted FAL services by AREP role.....	431
6.5 Conformance classes.....	435
6.6 Application characteristics.....	436
Bibliography.....	438
Figure 1 – Example of DP communication with a single controlling device.....	35
Figure 2 – Example of DP communication with several controlling devices.....	35
Figure 3 – Example of DP communication between field devices.....	36
Figure 4 – DP-slave model (modular DP-slave).....	38
Figure 5 – DP-slave model (compact DP-slave).....	39
Figure 6 – Overview of application processes.....	40
Figure 7 – DP-slave model (modular DP-slave).....	41
Figure 8 – Application Service Elements (ASEs).....	43
Figure 9 – Application Process with application Objects (APOs).....	44
Figure 10 – Access to a remote APO.....	45
Figure 11 – Access to a remote APO for publisher/subscriber association.....	46
Figure 12 – Example of one AR with two AREPs.....	47
Figure 13 – Relation of a simple process data object to the real object.....	53
Figure 14 – Relation of a combined process data object to the real objects.....	55
Figure 15 – Sequence of an isochronous DP cycle with one DP-master (class 1).....	86
Figure 16 – Additional time relationships in a DP system operating in isochronous mode.....	88
Figure 17 – DP system with optimized isochronous DP cycle.....	89
Figure 18 – Buffered synchronized isochronous mode at the DP-master (class 1).....	91

Figure 19 – Enhanced synchronized isochronous mode at the DP-master (class 1)	92
Figure 20 – Input, output and PLL state machine interaction	92
Figure 21 – PLL state diagram	98
Figure 22 – OUTPUT state diagram	102
Figure 23 – INPUT state diagram	106
Figure 24 – Treatment of an alarm in the DP system	139
Figure 25 – Load Region state diagram for erasable memory	237
Figure 26 – Load region state diagram for non erasable memory	238
Figure 27 – Function invocation state diagram	270
Figure 28 – System architecture	284
Figure 29 – Assignment of communication relationship to application relationship	291
Figure 30 – MS0 application relationship	297
Figure 31 – Output buffer model of a DP-slave without sync functionality	298
Figure 32 – Output buffer model of a DP-slave with sync functionality	298
Figure 33 – Input buffer model of a DP-slave without freeze functionality	299
Figure 34 – Input buffer model of a DP-slave with freeze functionality	299
Figure 35 – MS1 application relationship	300
Figure 36 – MS2 application relationship	300
Figure 37 – Example of inter-network communication	302
Figure 38 – Example without inter-network addressing	302
Figure 39 – First example with inter-network addressing	303
Figure 40 – Second example with inter-network addressing	304
Figure 41 – MS3 application relationship	305
Figure 42 – MM1 application relationship	305
Figure 43 – MM2 application relationship	306
Figure 44 – Cycle time of the DP system	437
Table 1 – Requirements and features of fieldbus DP	34
Table 2 – Status values of the service primitives	51
Table 3 – Access Rights MS1	54
Table 4 – Access Rights MS2	54
Table 5 – Access Rights MS1	57
Table 6 – Access Rights MS2	57
Table 7 – SCL matching rules	58
Table 8 – Read	58
Table 9 – Write	60
Table 10 – Data transport	61
Table 11 – Format (simple input data description)	65
Table 12 – Consistency (simple input data description)	65
Table 13 – Format (simple output data)	67
Table 14 – Consistency (simple output data)	67
Table 15 – Format (extended input data)	68
Table 16 – Consistency (extended input data)	69

Table 17 – Format (extended output data)	70
Table 18 – Consistency (extended output data)	71
Table 19 – Set Input	72
Table 20 – Read Input	72
Table 21 – Get Input	74
Table 22 – New Input	75
Table 23 – Set Output	76
Table 24 – Final	77
Table 25 – Read Output	77
Table 26 – Get Output	78
Table 27 – Clear Flag	78
Table 28 – New Flag	79
Table 29 – New Output	79
Table 30 – Clear Flag	79
Table 31 – Global Control	80
Table 32 – Clear Command	80
Table 33 – Sync Command	80
Table 34 – Freeze Command	81
Table 35 – New publisher data	81
Table 36 – Get publisher data	82
Table 37 – New Flag	82
Table 38 – SYNCH	83
Table 39 – SYNCH Delayed	83
Table 40 – DX Finished	84
Table 41 – SYNCH Event	84
Table 42 – Status	84
Table 43 – Primitives issued by the AL to the PLL state machine	94
Table 44 – Primitives issued by the user to the PLL state machine	94
Table 45 – Allowed values of Status	94
Table 46 – Primitives issued by the user to the input state machine	95
Table 47 – Primitives issued by the user to the output state machine	95
Table 48 – Primitives issued by the PLL to the output state machine	95
Table 49 – Primitives issued by the output to the PLL state machine	95
Table 50 – Primitives issued by the PLL to the input state machine	95
Table 51 – Primitives issued by the output to the input state machine	96
Table 52 – Primitives issued by the output state machine to the AL	96
Table 53 – Primitives issued by the AL to the output state machine	96
Table 54 – Primitives issued by the input state machine to the AL	96
Table 55 – Primitives issued by the AL to the input state machine	96
Table 56 – PLL state table	99
Table 57 – OUTPUT state table	103
Table 58 – INPUT state table	107
Table 59 – Identifier status	109

Table 60 – Channel type	110
Table 61 – IO type	111
Table 62 – Status type	111
Table 63 – Status specifier	112
Table 64 – Status specifier	113
Table 65 – Module status	113
Table 66 – Status specifier	114
Table 67 – Link status	114
Table 68 – Link error	115
Table 69 – Set Slave Diag	116
Table 70 – Ext Diag Flag	117
Table 71 – Get Slave Diag	119
Table 72 – Read Slave Diag	128
Table 73 – New Slave Diag	138
Table 74 – Alarm type	140
Table 75 – Add Ack	141
Table 76 – Alarm specifier	141
Table 77 – Alarm notification	142
Table 78 – Alarm Ack	143
Table 79 – Prm data type	148
Table 80 – Supported feature	158
Table 81 – Supported profile feature	158
Table 82 – Role	159
Table 83 – Check user Prm	160
Table 84 – Prm structure	161
Table 85 – MS1 Command	164
Table 86 – Check user Prm result	165
Table 87 – Status values	166
Table 88 – Check Ext user Prm	167
Table 89 – Check Ext user Prm result	170
Table 90 – Status values	171
Table 91 – Check Cfg	171
Table 92 – Check Cfg result	172
Table 93 – Status values	173
Table 94 – Set Cfg	173
Table 95 – Get Cfg	174
Table 96 – Set Slave Add	175
Table 97 – Initiate	176
Table 98 – Abort	179
Table 99 – Instance	179
Table 100 – MS0 init DP-slave	180
Table 101 – MS1 init DP-slave	180
Table 102 – MS2 init DP-slave	181

Table 103 – DP-slave started.....	181
Table 104 – Alarm limit.....	182
Table 105 – DP-slave stopped.....	182
Table 106 – Reset DP-slave.....	183
Table 107 – DP-slave fault.....	183
Table 108 – Application ready DP-slave.....	183
Table 109 – Start subscriber.....	184
Table 110 – Stop subscriber.....	184
Table 111 – Publisher active.....	185
Table 112 – Status.....	186
Table 113 – Init DP-master CI1.....	186
Table 114 – DP-master CI1 started.....	187
Table 115 – Alarm limit.....	188
Table 116 – DP-master CI1 stopped.....	188
Table 117 – Reset DP-master CI1.....	188
Table 118 – DP-master CI1 fault.....	189
Table 119 – DP-master CI1 reject.....	189
Table 120 – Set mode DP-master CI1.....	190
Table 121 – DP-master CI1 mode changed.....	191
Table 122 – Load bus Par DP-master CI1.....	192
Table 123 – Mark DP-master CI1.....	193
Table 124 – Abort DP-master CI1.....	193
Table 125 – Read value DP-master CI1.....	194
Table 126 – Delete SC DP-master CI1.....	194
Table 127 – DP-master CI1 event.....	195
Table 128 – Init DP-master CI2.....	196
Table 129 – Reset DP-master CI2.....	197
Table 130 – DP-master CI2 fault.....	197
Table 131 – DP-master CI2 reject.....	197
Table 132 – DP-master CI2 closed.....	198
Table 133 – DP-master CI2 event.....	198
Table 134 – USIF state.....	199
Table 135 – Data rate.....	203
Table 136 – USIF state.....	204
Table 137 – Isochronous mode.....	204
Table 138 – Slave type.....	207
Table 139 – Alarm mode.....	208
Table 140 – Get Master Diag.....	211
Table 141 – MDiag identifier.....	211
Table 142 – Start Seq.....	212
Table 143 – Area code (start seq).....	213
Table 144 – Download.....	214
Table 145 – Upload.....	215